

# LX PATCH CHART (Standard Rig)



Standard Rig

**Brentwood THEATRE**

Aug-17

Ch	Dim	Circuit(s)	Lantern	Number	Colour	TRS (ft)	Grelco	Notes
1	1	38 & 42	Source 4 15-30°	2	205	10		
2	2	56 & 41	Source 4 15-30°	2	202	10		
3	3	40	Source 4 15-30°	1	089	10		Gobo (leaf)
4	4	55	Source 4 36°	1				Aisle light
5	5	39	Source 4 15-30°	1	089	5		Gobo (leaf)
6	6	13	Source 4 26°	1				
7	7	15 & 18	Par 64	2	139			
8	8	20	Source 4 26°	1				
9	9	14	Source 4 Jnr.	1				
10	10	19	Source 4 Jnr.	1				
11	11	E10 & 47	Par 64	2	106	5 & 15		
12	12	E2 & E11	Par 64	2	135	10		
13	13	E1 & E12	Par 64	2	180	10		
14	14	24	Selecon Rama	2	205	5	1	
15	15	23	Selecon Rama	2	202	5	1	
16	16	22	Selecon Rama	2	205	5	1	
17	17	21	Selecon Rama	2	202	5	1	
18	18	E8	Source 4 36°	1				Aisle light
19	19	E9	Source 4 Jnr.	1		5		
20	20	E6	Quartet Fresnel	2	205	5	1	
21	21	E5	Quartet Fresnel	2	202	5		
22	22	E7	Source 4 Jnr.	1				
23	23	E4	Source 4 36°	2		15	1	Gobo (Leaf)
24	24	E3	Source 4 Jnr.	1				
25	25	49 & 52	Harmony F	2	202			
26	26	50 & 53	Harmony F	2	205			
27	27	51 & 54	Source 4 Jnr.	2				Mirror Ball
28	28	27	Patt 743	2	205	5	1	
29	29	28	Patt 743	2	202	5	1	
30	30	29	Patt 743	2	205	5	1	
31	31	30	Patt 743	2	202	5	1	
32	32	26 & 31	PAR 56	4	180		2	
33	33	25 & 32	PAR 64	2	139			
34	34	D2 & Ext.	PAR 64	2	128			

**Ch** - Desk channel number  
**Dim** - Channel on racks  
**Number** - Number of lanterns  
**Colour** - Lee colour code  
**TRS** - Length of TRS required, in feet

## LX PATCH CHART (Standard Rig)

Ch	Dim	Circuit(s)	Lantern	Number	Colour	TRS	Grelco	Notes	
35	35	35	Patt 833	2	205	5	1		
36	36	36	Patt 743	1	161	2			
37	37	34	Patt 833	2	205	5	1		
38	38	33	Patt 743	1	161				
39	39	4	Quartet Fresnel	3	205	2x5 1x10	2		
40	40	5	Quartet Fresnel	3	161	2x5 1x10	2		
41	41	3 & 6	Source 4 70°	2				Gobo (leaf)	
42	42	2 & 7	PAR 64	2	180				
43	46	1	PAR 64	2	106	25	1		
44	47	8	PAR 64	2	135	25	1		
45	48	11	Patt 833	2	205	5	1		
46	49	12	Patt 743	1	161	2			
47	50	10	Patt 833	2	205	5	1		
48	51	9	Patt 743	1	161	2			
49	52	IWB 6	Source 4 Jnr	1					
50	53	IWB 5	Source 4 Jnr	1					
51	54	IWB 4	Source 4 Jnr	1					
52	55	IWB 3	Source 4 Jnr	1					
53	56	IWB 2	Source 4 Jnr	1					
54	57	IWB 1	Source 4 Jnr	1					
55			<b>NOT CURRENTLY USED</b>						
56									
57									
58	43	37	Patt 23	1		20ft		BTT Logo gobo	
59	44	16 & 17	Coda (2x200 2x300)	4	151-ish	2x15	2	House	
60	45	D4 & Ext	Coda (2*500)	2	151-ish			House	

**Note:**  
Houselights are softpatched to channels 58-60.

# LX PATCH CHART (Standard Rig)

## *Intelligent Fixtures*

Ch	Addr	Channels	Fixture	Number	Notes
71	71	1	Hazer	1	Haze
72	72	1	Hazer	1	Fan
101	101-108	8	Studio COB	1	
102	109-116	8	Studio COB	1	
103	117-124	8	Studio COB	1	
104	125-132	8	Studio COB	1	
105	133-140	8	Studio COB	1	
106	141-148	8	Studio COB	1	
107	149-156	8	Studio COB	1	
108	157-164	8	Studio COB	1	
109	165-172	8	Studio COB	1	
110	173-180	8	Studio COB	1	
<b>181-199 Unused</b>					
200	200-207	8	ETC Selador Palletta	1	
201	208-215	8	ETC Selador Palletta	1	
202	216-223	8	ETC Selador Palletta	1	
203	224-231	8	ETC Selador Palletta	1	
204	232-239	8	ETC Selador Palletta	1	
205	240-247	8	ETC Selador Palletta	1	
206	248-255	8	ETC Selador Palletta	1	
207	256-263	8	ETC Selador Palletta	1	
208	264-271	8	ETC Selador Palletta	1	
209	272-279	8	ETC Selador Palletta	1	
210	280-287	8	ETC Selador Palletta	1	
211	288-295	8	ETC Selador Palletta	1	

Intelligent fixtures are all marked with their DMX start address.

If the DMX address is changed during the course of your rig, please return the fixture to the correct address, mode and rig position.

All studio cobs are operated in 8 channel mode.

All Pallettas are addressed for 8 channels per half batten.